

**Available Model**

*For Various Brand Battery*

**NOKIA**

NK 1200  
NK 2100  
NK 2600C  
NK 2680S/7610S  
NK 3120C/E66  
NK 3210  
NK 3220/3230  
NK 3310  
NK 5220  
NK 5310  
NK 5800  
NK 6100  
NK 6111  
NK 6500C  
NK 6500S  
NK N70  
NK 6708  
NK 8250  
NK 8800  
NK E71/E90  
NK N73/6280  
NK N73/6280/9300  
NK N81/N82  
NK N85/86  
NK N95 (8gb)  
NK N95/E65  
NK N-GAGE QD

BL-5CA  
BLD-3  
BL-5BT  
BL-4S  
BL-4U  
BML-3  
BL-5B  
BLC-2  
BL-5CT  
BL-4CT  
BL-5J  
BL-4C  
BL-4B  
BL-6P  
BP-5M  
BL-5C  
  
BLB-2  
BL-5X  
BP-4L  
BP-6M  
BP-6M  
BL-6MT  
BL-5K  
BL-6F  
BL-5F  
BL-6C



**SONY ERICSSON**

SE J132  
SE K700  
SE K750  
SE K750/W800  
SE K800  
SE P1i  
SE P800/900  
SE S500/W580/K770/K850  
SE T610/T630  
SE W200/J300/K510  
SE W910/W380/Z555  
SE X1  
SE K800  
SE K750

BST-42  
BST-30  
BST-37  
BST-37  
BST-33  
BST-40  
BST-15  
BST-38  
BST-25  
BST-36  
BST-39  
BST-41  
BST-33  
BST-37

SE K770/W580  
SE W910/W380/Z555

BST-38  
BST-39

**MOTOROLA**

MT A1000	
MT C115/V171/C139	
MT C168	BT-60
MT C200	
MT C300	
MT C350	
MT C380/650	
MT E398	
MT E6	BC-70
MT L6	BC-50
MT L7/V3X/C261	BC-60
MT L7e/L9/E8	BK-60
MT MPX220	
MT V3	BR-50
MT V360/W220/W375	BT-50
MT V3XX	BZ-60
MT V8	BX-40
MT V9	BX-50

**SAMSUNG**

SAM C100	SAM E700
SAM C200	SAM E720
SAM D500	SAM E770
SAM D600	SAM E810
SAM D720/E250	SAM L760
SAM D820/P300/P830	SAM M610
SAM D830/820/U600/E840	SAM X100
SAM D840	SAM X150/X160/X200/X680/C120/E900
SAM D900	SAM X430
SAM E100	SAM X460
SAM E310	SAM X480
SAM E330	SAM X600
SAM E350	SAM X620/X120
SAM E360	SAM X640
SAM E370	SAM X660
SAM E600	